

# Safe Electronic Manual



## FIRST OPENING

1. Please remove blue oval cover from front keypad.
2. Now insert key supplied and turn anti – clockwise.
3. Open the door by turning knob clockwise.
4. With the door in open position insert the 4 x AA batteries supplied.

## SETTING PERSONAL CODE

1. Put the door in a open position.
2. Press the **RED** button on the inside of the door.
3. Enter your **personal code**. *(it is recommended to use 4 numbers)*
4. Press the '#' button on the keypad to confirm.
5. Your personal code is now set.

## SETTING MASTERCODE

1. Put the door in a open position.
2. Press the **"0"** twice on the keypad.
3. Press the **RED** button on the inside of the door.
4. Enter your **mastercode** of your own choice. *(max 8 digits)*
5. Press the '#' button on the keypad to confirm.
6. Your mastercode is now set.

## **WARNING**

Before closing the door, check that the new codes are in operation. Enter your new personal code and press the '#' button on the keypad. The green indicator will light followed by a beep tone. Repeat for your mastercode. The safe is now ready to use.

## **OPENING YOUR SAFE**

Enter your personal or mastercode and press the '#' button on the keypad.

## **REPLACEMENT BATTERIES**

When the batteries are low the red indicator light will be illuminated when the keypad buttons are pressed. The lock uses 4 x AA batteries located in the battery holder. Please replace these as soon as possible.

## **INSTALLATION**

Use two 6mm bolts to bolt the safe to a suitable floor or wall.

## **MANUAL OVERRIDE**

Follow the step "First Opening".

# Kluis elektronisch Handleiding



## EERSTE OPENING

1. Verwijder de blauwe ovalen kap van het voorpaneel.
2. Gebruik de meegeleverde sleutel en draai deze tegen de klok in.
3. Open de deur door deze met de klok mee te draaien.
4. Met de deur open plaats de meegeleverde 4 x AA-batterijen erin.

## PERSOONLIJKE CODE INSTELLEN

1. Zet de deur in een open positie.
2. Druk op de **RODE** knop aan de binnenkant van de deur.
3. Voer uw persoonlijke code in. *(Aanbevolen om 4 cijfers te gebruiken)*
4. Druk op de '#' knop op het toetsenbord om te bevestigen.
5. Uw persoonlijke code is nu ingesteld.

## MASTER CODE INSTELLEN

1. Zet de deur in een open positie.
2. Druk **tweemaal op de "0"** op het toetsenbord.
3. Druk op de **RODE** knop aan de binnenkant van de deur.
4. Voer uw master code in. *(max. 8 cijfers)*
5. Druk op de '#' knop op het toetsenbord om te bevestigen.
6. Uw master code is nu ingesteld.

## **WAARSCHUWING**

Controleer voordat u de deur sluit of de nieuwe codes in werking zijn. Voer uw nieuwe persoonlijke code in en druk op de knop '#' op het toetsenblok. De groene indicator licht op gevolgd door een pieptoon. Herhaal voor je mastercode. De kluis is nu klaar voor gebruik.

## **DE KLUIS OPENEN**

Voer uw persoonlijke of master code in en druk op de knop '#' op het toetsenblok.

## **BATTERIJEN VERVANGEN**

Wanneer de batterijen bijna leeg zijn, gaat het rode indicatielampje branden wanneer de toetsen van het toetsenbord worden ingedrukt. Het slot gebruikt 4 x AA-batterijen in de batterijhouder. Vervang deze zo snel mogelijk.

## **INSTALLATIE**

Gebruik twee 6 mm bouten om de kluis vast te schroeven op een geschikte vloer of muur.

## **HANDMATIG OPNIEUW INSTELLEN**

Volg de stap "Eerste opening".