

MOUNTING INSTRUCTIONS FOR CARCASS BIN 800 L ON FRAME

03/06
N° GME9-3C

CONTENTS OF KIT

A. Bin + Cover	1	
B. Omega (1315*116)	2	
C. End of base (750*364)	2	
D. Flat metal interior plate (122*122)	2	
E. Fixed wheel Ø 200	2	
Maximum weight 205 kg / wheel		
F. pivoting wheel with brake	1	
Pivoting wheel without brake	1	1
G. Overhead beam	1	
H. Stop (L = 900 mm)	1	


CONTENTS OF SCREW BAG

Hexagon head bolt M 14-50	2
Hexagon head bolt M 10-20	32
Mushroom head bolt M 10-20	8
brake nut M 14	4
nut M 10	40
Washer Ø 14	2
Washer Ø 10	8
Compression spring 18,5*92	1
Latch	1
Split pin Ø 4*40	1
Black plastic cap 100 x 50	2



ORDER OF ASSEMBLY

- * fix the wheels on the omega (B) with the bolts M10-20 and nuts M10.
- * Fix the 2 ends of base on the omegas (using washers on oblong holes)
- * put the bin on the frame that you just mounted. Drill the corresponding holes in bin and bolt together (bin and end of base) on metal interior plate using bolts M 10-20.
- * Fix overhead beam to base and bin (see detail B)..
- * Insert latch (see detail A).
- * Fix stop bar opposite to latch, drill and assemble using mushroom head bolts M 10-20.

NOTE : Check height and depth of stop bar in respect to latch before drilling the bin.



DETAIL A Mounting of latch



DEALER INFORMATION

Delivery : in kit form
Approx. weight: 110 Kg / unit
Packaging : per 5 units
Dimensions = 1800*1150*1530 mm
(L * w * h)



F - 72550 COULANS SUR GEE

FRANCE - Fax: (+33) 243.88.72.99

http://www.lanee.com lanee.nlv@wanadoo.fr

CARCASS BIN 600L ON CHASSIS WITH CRANE

09/21
N° GME9-4D

KIT CONTENT

- Bin with cover 1
- Box of accessories 1

BOX OF ACCESSORIES

- A - Flange 1
- B - Flange with stop 1
- C - Crane 1
- D - Fixed wheel 2
- E - Pivoting wheel 1
- F - Pivoting wheel with brake 1
- G - Reinforced plate 1
- Screw bag 1

SCREW BAG

- Fastener 2
- Spring 18,5*92 1
- Bolt 1
- Pin V4-40 1
- Rubber rope Lg250mm 2
- Screw TH M10 x 70 stainless steel 6
- Screw TH M10 x 20 Zn 18
- Screw TH M6x25 Zn 4
- Brake nut M10 24
- Brake nut M6 4
- Rope Ø8 Lg4m 1
- Cable clamp Ø8 Zn 1
- Washer Ø 10 LL stainless steel 12
- Document GME9-F 1
- Sticker category 1 1
- Sticker category 2 1
- Sticker catégorie 3 1

MOUNTING

- Fix the wheels on parts A and B with the screws TH M10x20 Zn + brake nut M10 Zn. (nuts on wheel's side)
- Set the bin upside down. Drawing B
- Set A and B on the bin et fix G by with the screws TH M10x20 Zn+ brake nut M10 Zn - Drawing B.
- Set the 2 flanges on the bin with the screws TH 10x70 Inox + Brake nut M10 + washer Ø10 LL Inox (nut=outside the bin) – Drawing C
- Put the bin in the standard upright position.
- Place the 2 rubber ropes through the cover - Drawing E
- Use a screwdriver to make the U opening wider in order to fix the ropes- Drawing D
- Set the bolt on the crane C as shown on drawing A.
- Fix the crane as shown on the drawing C and fix the fasteners with the screws TH M6x25+ Brake nut M6.
- Set the rope Ø8 on the ring (drawing A) and fix it with cable clamp Ø8 Zn.

